


# ANGELINA TABLE LAMP

## MODEL # 3327



### PLEASE READ AND SAVE THESE INSTRUCTION:

1. REMOVE ALL PARTS AND LAY ON A FLAT SURFACE.
2. SET SHADE (B) ON SOCKET (A) AND TIGHTEN CLOCKWISE WITH SOCKET RING (C) TO SECURE SHADE.



### MAINTENANCE:

This lamp requires the use of a maximum 13-watt CFL light bulb or a 60-watt maximum standard incandescent bulb. Wattages listed are maximums - lower wattages may be used.

### IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug ( one blade is wider than the other ) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. **DO NOT ALTER PLUG.**



21 Penn Plaza #909 New York, NY 10001  
Tel : (212) 736 4440 Fax : (212) 736 4806